



INVICTA
Movement Caliber
9238 / 1970

INFO Battery: 371 – SR920SW

Movement Caliber : 9238 / 1970

Presentation

Display Elements

Minute Hand


Hour Hand

Day

Second Hand

Date

24-hour / second
time zone



Control Buttons

Push Button C (Option)

Quick correction of day

Push Button A

Quick correction of date

Crown Positions:

1. Normal Running

2. Setting of Hour, Minute,
Date, 24-Hour

Push Button B




Quick correction of 24-hour,
second time zone

Movement Caliber : 9238 / 1970

Setting

Setting the Time and 24 Hour

- 1.1 Pull the crown to position 2.
- 1.2 Turn the crown clockwise to set the hour, minute and 24 hour hands to the desired time.
- 1.3 Push the crown back to position 1.



Movement Caliber : 9238 / 1970

Setting

Setting the Second Time Zone

- 2.1 Set the crown to position 1.
- 2.2 Press B step-by-step to advance the hand of the second time zone by one hour per step until the desired time is set.
- 2.3 Release the button after completing the setting.

!! Attention !!

When using push button B to set the second time zone hour, the center minute hand must be set to between 55th minute and 05th minute at any hour.






Movement Caliber : 9238 / 1970

Setting

Setting the Date

- 3.1 Pull the crown to position 2.
- 3.2 Turn the crown clockwise. Continue to turn the crown until the desired date is set.
- 3.3 Push the crown back to position 1.



Movement Caliber : 9238 / 1970

Setting

Quick Correction of Date

4.1 Set the crown to position 1.

4.2 Press A step-by-step to advance the date until the desired date set.

!! Attention !!

The date advances at 00:00 midnight, not 12:00 noon.



Movement Caliber : 9238 / 1970

Setting

Setting the Day

- 5.1 Pull the crown to position 2.
- 5.2 Turn the crown clockwise to advance the day hand until the desired day is set. The day hand will advance one day when 04:00 in the morning is reached.
- 5.3 Push the crown back to position 0.



Movement Caliber : 9238 / 1970

Setting

Quick Correction of Day

- 6.1 Set the crown to position 1.
- 6.2 Press A step-by-step to adjust the month to the desired one.
- 6.3 Press C twice to advance the day hand by one step until the desired day is set.

!! Attention !!

Do not use Quick Correction to set the Day between 22:00 at night and 6:00 in the morning.

